

For cork, leather, or vinyl - The large tab will work with 1-1/2" wide hardware and the small tab will work with 1" wide hardware. For cotton fabric - The large tab will be sewn right sides together using 1/4" seam allowance and will work with 1" wide hardware. You may wish to topstitch the top half of the tab using 1/8" seam allowance, then attach to the purse hardware by folding the top of the tab toward the wrong side by 1" and placing the hardware and this fold, and finally sew the lower half of the tab to the bag.